

How to setup 10 foot Tent Trailer

- ☐ Lower outside Jacks
- ☐ Release levers for roof and raise roof with power switch at front of trailer
- ☐ Insert "black" support bars (from under mattress) and pull out side beds
- ☐ Attach "brass color" metal safety supports for roof rails
- ☐ Attach and seal trailer canvas all around trailer sides
- ☐ Remove black "sink" drain cover from outside of trailer (next to shower cover)
- ☐ From inside trailer attach "white" poles (from under mattress) to support inside beds
- ☐ Lower front door from inside ceiling and attach to trailer front opening
- ☐ Turn ON Propane from front of trailer
- ☐ Start "propane" Fridge

(FROM OUTSIDE) Remove vent cover to locate controls for propane fridge, turn "GREY" knob to HIGH, while holding down "GREY" knob push RED ignitor button 2-3 times quickly. Should hear a CLICK and burner flame should ignite BLUE

- ☐ From inside trailer, Turn ON Hot water tank switch below couch

RED light should go off in about 20 seconds, that means the propane ignitor has started to heat water

You will hear a faint flow of gas to the heater, this is normal

- ☐ From inside trailer, Turn ON the Sink pump switch under couch

This pump will go on everytime the sink taps are turned but will go off when taps are may take several seconds for pump to go off, it should not run for a long time, if so turn switch off /on again

How to put down 10 foot Tent Trailer

- ☐ Detach and raise front door
- ☐ Remove "white" support poles from side beds (store under mattress)
- ☐ Turn OFF sink and hot water switches (by couch)
- ☐ Pull out sides of canvas all around trailer and tuck inside
- ☐ Push in side beds on each side and store Black support poles under mattress
- ☐ Lower roof 1/2 down and tuck in the side canvas
- ☐ Raise jacks on outside of trailer
- ☐ Turn OFF propane tank